


# Honeywell Configuration Bar Codes


Please scan the codes in the numbered order.

1. Enter Program Mode



999999

2. Internal Full Speed USB Defaults




999970

3. Configuration Code 1




8035350

4. Configuration Code 2



8036350

5. Exit Program Mode



999999